

brandeismakerlab

# How to Swap the Bed

How to swap the bed.

Written By: Harrison Goodman

## INTRODUCTION

How to swap the bed.

## Step 1 — How to Swap the Bed



- Grab the tab at the front of the print bed and pull gently to remove, be careful it may be hot
- Either remove your print from the bed replace or if it is someone else's print put it aside form them to remove later. Either way take a clean clear bed and put it back on the printer making the swappable print bed slide into place.